
Operating Instructions

1080I Multi-purpose Digital Camera

AK-HC910P





Before attempting to connect, operate or adjust this product, please read these instructions completely.

The



DO NOT REMOVE COVER (OR BACK). NO USER SERVICEABLE PARTS INSIDE. REFER TO SERVICING TO QUALIFIED SERVICE PERSONNEL.

lightning



arrowhead symbol, within an equilateral triangle, is intended to alert the user to the presence of uninsulated "dangerous voltage" within the product's enclosure that may be of sufficient magnitude to constitute a risk of electric shock to persons.

flash

with

The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance (service) instructions in the literature accompanying the appliance.

For CANADA This class A digital apparatus complies with Canadian ICES-003. Cet appareil numéique de la classe A est conforme à la norme NMB-003 du Canada.

FCC Note:

This device complies with Part 15 of the FCC Rules. To assure continued compliance follow the attached installation instructions and do not make any unauthorized modifications.

This equipment has been tested and found to comply with the limits for a class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference radio to communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

WARNING:

TO REDUCE THE RISK OF FIRE OR SHOCK HAZARD, DO NOT EXPOSE THIS EQUIPMENT TO RAIN OR MOISTURE.

CAUTION:

TO REDUCE THE RISK OF FIRE OR SHOCK HAZARD AND ANNOYING INTERFERENCE, USE THE RECOM-MENDED ACCESSORIES ONLY.

The serial number of this product may be found on the bottom of the unit.

indicates safety information.

CONTENTS

For Your Safety2
Preface4
Features4
Precautions
Major Operating Controls and
Their Functions6, 7
How to Install
How to set the lens8
How to install on the camera housing, pan/tilt head, tripod, etc
How to Set Up the System (Connection)9
Multi-purpose Digital Camera Control System Configuration 110
Multi-purpose Digital Camera Pan/Tilt Head Compatible System Configuration 111
Multi-purpose Digital Camera Control System Configuration 212
Multi-purpose Digital Camera Pan/Tilt Head Compatible
System Configuration 213
Operation Procedure14
How to Adjust15 to 17
Flange back adjustment (for zoom lens)15
Lens iris gain volume adjustment15
White balance adjustment16
Color temperature and white balance adjustment (reference)
Black balance adjustment17
Gen lock adjustment17

Setting of Menu Items18 to	29
Configuration of menu display	
screen	
USER menu (Initial screen)	.19
Maintenance menu	26
 Black shading correction 	
menu	.20
Pedestal, gamma, flare	04
adjustment menu	.21
3 Knee&white clip adjustment menu	იი
Gain adjustment menu	
5 Detail adjustment menu23,	24
Master gain, auto iris setting menu	24
7 Super gain, Detail, Pedestal-	.27
offset level setting menu	.25
B Matrix menu	
Solor correction 1 menu	
10 Color correction 2 menu	
2 Setting menu27,	
Camera mode setting	20
menu27,	28
2 Electronic shutter setting	
menu	.28
3 Horizontal phase adjustment	
menu for external reference	~~
signal	
Camera ID setting menu	.29
File managing and renewing	20
menu29,	
File operation menu	
Outside Dimension Diagram	
Specifications & Accessories	.32

Thank you very much for purchasing the multi-purpose digital camera.

Preface

This camera employs new 2/3" 2.2 million-pixel FIT CCD [1920(H) \times 1080(V)], realizing a compact light-weight system including the optical system.

Also, the newly developed CCD having an FIT configuration suited for higher picture quality and the development of low-noise, high-speed amplifiers have enabled the realization of high sensitivity, high S/N ratio, and wide dynamic range.

With the newly developed digital signal processing LSI mounted on the camera head, it performs signal processing such as GAMMA, KNEE and DTL matrix, and CCD flaw correction based on a new system, intending to improve the maneuverability with multifunction, high-guality, and high stability peculiar to a digital system.

Making the best use of the features of a small-sized self-contain camera, it is accommodated in the camera housing and able to provide high-quality HD pictures as an multi-purpose digital camera.

Features

New 2/3" 2.2 million-pixel CCD is employed. [1920(H) \times 1080(V)]

• 2.2 million-pixel CCD is 2/3" size, being compact and light-weight.

The camera section is equipped with a high picture quality digital signal processing LSI.

- 10 Bit, 74 MHz high picture quality digital processing after the process circuit.
- New type CCD flaw correcting function.
- High reliability, multi-function, and improvement of maneuverability are realized.
- Max. +48 dB gain-up is possible. (Memory addition, CCD pixel addition mode included)

Performance improvement by newgeneration FIT

- High sensitivity, wide dynamic range and low smear are realized by CCD most suited for high-quality pictures.
- High response and high resolution are realized by driving H-CCD at 74 MHz.

Multiple functions

- Multi-function DTL such as highluminance DTL and skin DTL.
- Two HD-SDI output lines.

DON'TS

- Do not attempt to disassemble the camera or other units. In order to prevent electric shock, do not remove screws or covers. There are no user-serviceable parts inside.
- Do not abuse the camera. Avoid striking, shaking, etc. The camera contains sensitive components which could be damaged by improper handling or storage.
- Do not let the lens remain uncapped when the camera is not use. If the lens is not installed, do not leave the lens mount hole uncovered.
- Do not touch the surface of the lens or prism.
- Do not use strong of abrasive detergents when cleaning the camera body.
- Do not aim the camera toward the sun, no matter whether it is turned on or not.
- Do not expose the camera to rain or moisture, and do not try to operate the equipment in wet conditions. Do not operate the camera if it becomes wet.
- Do not operate the camera outdoors during a lightning storm.
- Do not use the camera in an extreme environment where high temperatures or high humidity exist.
- Do not leave the camera turned on when not in use. Do not unnecessarily turn the camera power on and off repeatedly. Do not block the ventilation slots.
- Do not cover the port otherwise block ventilation during operation. Internal heat buildup can cause a fire.

DO'S


- Refer any servicing to qualified service personnel.
- · Handle the camera with care.
- Protect the precision made lens by placing the lens cap over when the camera is not in use. If the lens is not installed, protect the surface of the prism by placing the body cap into the lens mount hole.
- Use a mild blower or lens cleaning tissue designed for coated lenses, to clean the surface of the lens or prism in the event that it should become dirty.
- Use a dry cloth to clean the camera if it is dirty. In case the dirt is hard to remove, use mild detergent and wipe gently.
- Use caution when operating the camera in the vicinity of spot lights or bright lights, as well as light reflecting objects and surfaces.
- Take immediate action if ever the camera should become wet. Turn the power off and have the unit checked by an authorized service facility.
- Follow normal safety precaution to avoid personal injury.
- Use the camera in an environment where the temperature is within 32°F to +104°F (0°C to +40°C), and the relative humidity is within 30% to 90% (no condensation).
- Always turn the power off when the camera is not going to be used. Operate the camera only when there is adequate ventilation.

Cooling fan

There is internally provided a cooling fan. Since the cooling fan is a consumable part, replace it after about 50,000 hours of operation.

(Be sure to ask the dealer for the replacement.)

Front Panel



Lens Mount

2/3" standard bayonet type (B4 mount) lens is installed.

Lens Fixing Ring Knob


Lens is fixed by turning the knob counterclockwise.

Cable Clamp

Used to clamp the lens cable.


4 Lens Connector [LENS]

Used to connect the camera cables of the lens.



Pin No.	Signal	Pin No.	Signal
1	Return control	7	Iris follow
2	VTR-S/S	8	Iris auto selection
3	UNREG GND	9	
4	Iris manual selection	10	
5	Iris control	11	
6	UNREG 12V	12	NC

Top and Bottom Panels



Cooling Fan

- Do not block or obstruct the ventilation during operation. It may otherwise cause internal heating or fire.
- The life of this fan is approximately 50,000 hours (at room temp. 25°C). Replace the fan as needed.


(When the room temperature is higher than 35°C, replace the fan earlier.) Be sure to ask the dealer for the replacement.

G Camera mounting hole (1/4-20UNC)

Camera mounting hole (3/8-16UNC)

The screw holes can be used to secure the camera for installing it on camera housing, and when using a pan/tilt head or a tripod.

Side Panel



③ Breaker [BREAKER]

If the breaker is operated due to over-current or the like, check the cause and eliminate the trouble, then press the breaker button.

O Zoom/Focus Connector [ZOOM/FOCUS]

Used to connect the zoom/focus control cables of lens.




Pin No.	Signal	Pin No.	Signal
1	Focus control selection	7	СОМ
2	Zoom control selection	8	Focus control
3	GND	9	Zoom control
4	Forcible iris closing	10	Iris control selection
5	Iris control	11	COM +Voltage
6	+Voltage	12	COM –Voltage

SDI Output Connectors [SDI OUT 1, 2]

SDI signal output is given by two lines.

Interface Connector [I/F]




Pin No.	Signal	Pin No.	Signal
1	Y signal output	8	Y signal GND
2	Pb signal output	9	Pb signal GND
3	Pr signal output	10	Pr signal GND
4	Sync signal input	11	Sync signal GND
5	DC 12V	12	DC GND
6	Frame GND	13	TXD (C)
7	TXD (H)	14	RXD (H)
		15	RXD (C)

TXD: Data from Camera to remote controller RXD: Data from remote controller to camera

How to set the lens

- Standard 2/3" bayonet type (B4 mount) lens of any makers can be used*.
- ① Turn the lens fixing ring knob counterclockwise to remove the lens mount cap.
- ② Set the lens in place, and turn the lens fixing ring knob clockwise to precisely fix the lens.
- (3) Connect the lens cable to the lens connector.
- ④ Connect the remote (zoom/focus control) cable to the zoom/focus connector on the rear panel.
- * Note that there are some lenses uncontrollable with respect to zoom, focus function.




How to install on the camera housing, pan/tilt head, tripod, etc.

- (1) Precisely set the camera on the camera housing, pan/tilt head, tripod, etc. by using the camera set-screw hole (1/4-20UNC, 3/8-16UNC).
- ② When mounting the camera on a pan/tilt head, be sure to use proper tools and make sure that there is no fear of falling off.


Connection of remote control box

· Use multi-cable for the connection of HD controller AK-HRP900 and this unit.




- ① Before connecting the cables, be sure to set the Power Switch of AC Adaptor and HD Controller to OFF.
- ② Connect the multi-cable to the interface connector of the camera, and the opposite side to HD Controller.
- ③ Set the AC Adaptor Power Switch to ON, and the HD Controller Power Switch to ON, then the camera can be controlled.
- ④ After shooting, set the HD Controller Power Switch to OFF, and the AC Adaptor Power Switch to OFF.


Multi-purpose Digital Camera Control System Configuration 1




Multi-purpose Digital Camera Pan/Tilt Head Compatible System Configuration 1



(System for remotely monitoring picture control)



(System for remotely monitoring picture control)



AW-PS301

- **1** Turn on the power of each equipment.
- 2 Properly adjust the light for the object.
- **3** Adjust the flange back of the lens, the iris and the focus.
 - Flange back must be adjusted when the camera is used for the first time or after replacement of the lens.

4 Adjust the white balance.

- This adjustment is needed when the camera is used for the first time or after leaving unused for a long time.
- The adjustment is necessary when the lighting condition or brightness is changed.
- After adjusting the white balance once, re-adjustment is not needed under the same condition.

5 Adjust the black balance.

- This adjustment is needed when the camera is used for the first time or after leaving unused for a long time.
- The adjustment is necessary when the ambient temperature is greatly changed or at the change of season.
- After adjusting the black balance once, re-adjustment is not needed under the same condition.

6 Start shooting.


(After shooting, be sure to turn off the power of each equipment connected.)

Flange back adjustment (for zoom lens)

The adjustment is to adjust the focus in all the range from the maximum zoom to the widest angle of the zoom lens.

- 1) Shoot a dark object to open the iris.
- ② Adjust the distance from the object to 6.6 ft. (2 m) at least, then loosen the flange back fixing knob of the lens.
- ③ Set the lens to the maximum zoom and adjust the focus by turning the focus ring.
- ④ Set the lens to the widest angle and adjust the focus by turning the flange back adjust ring.
- ⑤ Repeat adjusting the focus ring and flange back adjust ring until the focus is adjusted within the zooming range.


After finishing the adjustment, tighten the flange back fixing knob.



Flange Back Adjust Ring

Lens iris gain volume adjustment

- Iris gain adjust hole (G or S) is provided at front of the lens housing. Adjust the iris according to the following procedure by using a screwdriver.
- ① Set the iris select switch of the lens to A "AUTO" side.
- ② Turn the iris gain adjust volume to maximize the gain in such extent that no hunting takes place.
- * Iris PEAK/AVE of camera menu can also be used for the adjustment.




White balance adjustment

Adjust the white balance after shooting a white object by at least 50% of the screen. **NOTE:** If the white signal level is over 100% or less than 50%, the white balance may not be normally adjusted.

Color temperature and while balance adjustment (reference)

When carbon is burnt, it develops various colors of light depending on the temperature. Natural light can be specified by color temperature reflecting to the color developed when carbon is burnt.

The light of 3.200K (K=Kelvin, -273°C equals to absolute zero temperature 0K) represents the same value (color) as what develops when carbon is burnt at 3,200K (2,927°C). The relationship between the color temperature of the light source and weather condition is indicated in the right figure. Let's study the difference of shooting an indoor object from shooting one outdoors. Studios are usually lighted with incandescent lamps and the color temperature of a white object in a studio is around 3,200K. The color temperature of a white object outdoors is around 6,500K. The former may look a little vellowish while the latter appears



Color temperature values

somewhat bluish when they are shot by a camera. However, the human eye does not recognize color differences among these objects even under different ambient lighting conditions, because of their adaptability to light.

The video camera reproduces color differences with high fidelity and the color of an object somewhat different from what appears to the human eye.

Therefore, there is a need to adjust the white balance in order to correct differences between color temperatures.

NOTE

Color temperature outdoors may vary depending on weather conditions.

Black balance adjustment

Adjust it with the lens closed.

When the motor drive lens is controlled from the camera, adjusting the black balance causes the lens to be automatically closed.

Gen lock adjustment

When multiple cameras are used or the camera is combined with other equipment, it is necessary to adjust the phase for phase matching by external synchronization.

Horizontal phase adjustment

Observe the waveforms of externally synchronizing signal input (black burst signal) and video signal output by a two-phenomenon oscilloscope, and make the horizontal phase according to the camera menu.


Adjustment with H.PHASE of SETTING menu

- Roughly adjust the synchronizing signal input and video signal output phases by H.PHASE-COARSE.
- ② Finely adjust the synchronizing signal input and video signal output phases by H.PHASE-FINE.

```
-**H.PHASE**
H.PHASE-COARSE :03
H.PHASE-FINE :40
```

H.Phase adjustment is executed by the HD Controller AK-HRP900.

Configuration of menu display screen



USER menu (Initial screen)

USER MENU

- -1.MAINTENANCE
- 2.SETTING
- 3.CAM ID
- 4.FILE MENU

The readout data at start of power supply is the data just before cutting off the power supply, and the operation is started with the data.

- 1. MAINTENANCE It sets various adjusting data.
- 2. SETTING It sets various modes.
- 3. CAM ID It sets the camera ID.

4. FILE MENU

It executes file loading and saving, and makes the basic setting of data display.

Menu operation is executed by the HD Controller AK-HRP900.

-*MAINTENANCE*

1.BLACK SHADING
2.PED, GAMMA, FLARE
3.KNEE,WHITE CLIP
4.R/B GAIN
5.DTL
6.GAIN,AUTO IRIS
7.S.GAIN 1
8.S.GAIN 2
9.S.GAIN 3
10.MATRIX
11.COLOR CORRECTION1
12.COLOR CORRECTION2

-*BLACK SHADING*		
DETECTION		
CORRECT(DIG)	:ON	
CORRECT (ANA)	:ON	

- Move the cursor (arrow mark) to the item to be adjusted and press the MENU key, then it enters the adjustment menu thereunder.
- Move the cursor to MAINTENANCE and press the MENU key, then it returns to USER MENU.

- **1** Black shading correction menu
 - When MENU key is pressed at DETECTION, (BLK-SHD:ACTIVE) appears, then the lens is automatically stopped down and ABB operation is executed.
 - When CORRECT (DIG) is turned ON, horizontal and vertical shading correction is automatically executed. When it is turned OFF, the current value is maintained.
 - Move the cursor to "BLACK SHADING" and press the MENU key, then it returns to MAINTENANCE MENU.
 - When CORRECT (ANA) is set to ON, vertical shading correction (SAW tooth) is automatically corrected.

Note:

It takes about 90 sec. until completion of black shading correction.

→**PED,GAMMA,FLARE	**
M PED	:+027
R PED	:+000
B PED	:+000
M GAMMA	:0.45
R GAMMA	:+00
B GAMMA	:+00
R FLARE	:010
G FLARE	:000
B FLARE	:017
GAMMA	:ON
FLARE	:ON

2 Pedestal, gamma, flare adjustment menu

M PED: Master pedestal can be adjusted only by turning the control panel VR.

The R, G, B pedestal can be totally adjusted.

R, B PED: R, B pedestal adjustment. Besides the master pedestal adjustment, R, B pedestal can be independently adjusted. It is not related to DATA REF. The numeral display after normal ending of ABB is "0" for both of R, B.

M GAMMA: Master gamma adjustment. The R, G, B gamma can be totally adjusted.

R, B GAMMA: R, B gamma adjustment. Besides the master gamma adjustment, R, B gamma can be independently adjusted.

R FLARE: R flare adjustment

G FLARE: G flare adjustment

B FLARE: B flare adjustment

GAMMA: Gamma ON/OFF setting

FLARE: Flare ON/OFF setting

→**KNEE,WHITE CLIP**	
M KNEE POINT	:95.00%
R KNEE POINT	:+00.00%
B KNEE POINT	:+00.00%
M KNEE SLOPE	:95.00%
R KNEE SLOPE	:+000
B KNEE SLOPE	:+000
A.KNEE POINT	:95.00%
A.KNEE LVL	:108
WHITE CLIP LVL	:109%
KNEE	:MANU
WHITE CLIP	:ON

3 Knee&white clip adjustment menu

M KNEE POINT: Master knee point adjustment.

G, B, R knee point can be totally adjusted.

R, B KNEE POINT: R, B knee point adjustment.

Besides the master knee point adjustment, R, B knee point can be independently adjusted.

M KNEE SLOPE: Master knee slope adjustment.

G, B, R knee slope can be totally adjusted.

R, B KNEE SLOPE: R, B knee slope adjustment.

Besides the master knee slope adjustment, R, B knee slope can be independently adjusted.

A. KNEE POINT: Auto knee point setting. Knee point in auto knee mode is set.

A. KNEE LVL: Auto knee level.

WHITE CLIP LVL: White clip level adjustment.

Video level with white clipped is set.

KNEE: KNEE mode (OFF/MANU/AUTO)

OFF: Knee function is turned OFF. MANU: Knee function is adjustable with menu.

AUTO: Auto knee function is executed.

WHITE CLIP: White clip operation setting.

With it ON, white clip is effective.

:+000

:+000

1 Maintenance menu

-**R/B GAIN**

R GAIN B GAIN

-**DTL**	
DTL	:ON
TOTAL DTL LVL	:+00
H DTL LVL	:11
CRISP	:02
LVL DEPENDENT	:2
PEEK FREQUENCY	:10
KNEE APERTURE	:ON
KNEE APA.LVL	:10
SLIM DTL	:OFF
DTL(+)	:+00
DTL(-)	:+00
DTL CLIP	:0
DTL SOURCE	:(B+G)/2

4 Gain adjustment menu

The gain of R, B GAIN is adjusted. The difference from the state of being white-balanced can be adjusted.

• The numeral value displayed after normal ending of AWB is "0" for both of R, B.

5 Detail adjustment menu

DTL: Setting of valid/invalid of detail function.

TOTAL DTL LVL: Horizontal and vertical detail level adjustment.

H DTL LVL: Horizontal DTL component is adjusted independently of DTL adjusted by TOTAL DTL.

CRISP: It functions to eliminate slight detail component and to reduce the noise level.

LVL DEPENDENT: It suppresses the detail of low brightness level. The brightness level to be suppressed is adjusted here.

PEAK FREQUENCY: It lifts up the detail component, and selects the central frequency.

KNEE APERTURE: It functions to emphasizes the detail component of the portion with knee applied.

KNEE APA.LVL: It sets the degree of knee aperture.

SLIM DTL: It validates the function of slimming the portion where the detail is thick and emphasized.

→**DTL**	
DTL	:ON
TOTAL DTL LVL	:+00
H DTL LVL	:11
CRISP	:02
LVL DEPENDENT	:2
PEEK FREQUENCY	:10
KNEE APERTURE	:ON
KNEE APA.LVL	:10
SLIM DTL	:OFF
DTL(+)	:+00
DTL(-)	:+00
DTL CLIP	:0
DTL SOURCE	:(B+G)/2

-**GAIN,AUTO IRIS**	
LOW GAIN	:0dB
MID GAIN	:9dB
HIGH GAIN	:18dB
A.IRIS LVL	:082
A.IRIS PEAK/AVG	:075
A.IRIS WINDOW	:NORM1
IRIS MODE	:LENS
IRIS GAIN	:06

5 Detail adjustment menu (continued from previous page)

DTL (+): Setting of DTL at the edge in positive direction.

DTL (–): Setting of DTL at the edge in negative direction.

DTL CLIP: Setting of clip level of DTL edge.

DTL SOURCE: Setting of video source [G, R, (3G+R) /4, (2G+R+B) /4, (G+B/2)] to create the detail.

6 Master gain, auto iris setting menu

LOW GAIN: LOW setting of master gain.

MID GAIN: MID setting of master gain.

HIGH GAIN: HIGH setting of master gain.

• The above GAIN setting is able to set -6 to +18 dB in 3 dB step.

A.IRIS LVL: Setting of the intended convergence level of auto iris.

A.IRIS PEAK/AVG: Setting of the detection ratio of peak value and average value of the quantity of light when auto iris is operated.

A.IRIS WINDOW: Setting of the detecting position of auto iris.

IRIS MODE: Auto iris mode setting: (LENS/CAM).

IRIS GAIN: Iris loop gain adjustment.

-**S GAIN 1**

*TOTAL GAIN	:42dB
ANLG GAIN	:36dB
PIX MIX	:06dB
H DTL LVL	:00
CRISP	:0
LEVEL DEPENDENT	:5
PEAK FREQUENCY	:2
M GAMMA	:0.45
MASTER PED OFFSET	:-043
R PED OFFSET	:-046
B PED OFFSET	:-045

(Super gain 1, 2, 3 are same menu.)

Super gain, Detail, Pedestal-offset level setting menu

TOTAL GAIN: Total gain in analog, pixel addition, and memory addition is displayed.

ANLG GAIN: Gain setting in analog.

PIX MIX: Gain setting in horizontal pixel addition. Capable of setting 0/6 dB.

H DTL LVL: DTL level setting of super gain.

CRISP: Setting the function of reducing noise level of super gain. It is invalid when DTL level is "0".

LEVEL DEPENDENT: Setting of DTL suppression at low lighting intensity of super gain.

PEAK FREQUENCY: Setting of DTL boost frequency of super gain.

M GAMMA: Gain setting in super gain. Capable of setting 0/6 dB.

MASTER PED OFFSET: Setting of master pedestal offset of super gain 1.

R PED OFFSET: Setting of R pedestal offset of super gain.

B PED OFFSET: Setting of B pedestal offset of super gain.

→< MATRIX	>	
MATRIX	TABLE	:A
MATRIX	R-G	:+00
MATRIX	R-B	:+00
MATRIX	G-R	:+00
MATRIX	G-B	:+00
MATRIX	B-R	:+00
MATRIX	B-G	:+00

-≺	COLOR	CORRECT	ION1 >	
		SAT	PHASE	
	R	+00	+00	
	Mg	+00	+00	
	в	+00	+00	
	Cy	+00	+00	
	G	+00	+00	
	Y1	+00	+00	

-< CO	L	OR CO	RRECT	ION2 >	
			SAT	PHASE	
R	-	Mg	+00	+00	
Mg	-	в	+00	+00	
в	-	Су	+00	+00	
Cy	-	G	+00	+00	
G	-	¥1	+00	+00	
¥1	-	R	+00	+00	

8 Matrix menu

Selection of table A, B or OFF. Adjustment of gain of each color.

9 Color correction 1 menu

Adjustment of gain (saturation) and phase of each color.

10 Color correction 2 menu

Adjustment of gain and phase of matrix.

2 Setting menu

-**SETTING**	
1.MODE	
2.SHUTTER	
3.H.PHASE	

-**MODE**	
BLACK STRETCH	:OFF
D5600K	:OFF
CABLE COMPE	: Om
SUP GAIN	:OFF
CAM ID	:BAR
CAM ID POSI	:0
MATRIX TABLE	:OFF
COLOR CORRECTION	:OFF
STATUS	:ON

Menu for various settings.

1 Camera mode setting menu

BLACK STRETCH: Setting of the function of expanding low-brightness analog video level. It is set by ON/OFF.

D5600K: It is able to make color temperature correction of about 5600 degrees of electric color temperature correcting file.

It is set by ON/OFF.

CABLE COMPE: Setting of video cable compensation. It is able to set 0/25/50m.

SUP GAIN: It sets OFF/1/2/3 of MAX GAIN.


CAM ID: Setting of camera ID display. It is set by OFF/BAR/ON. In BAR setting, CAM ID is displayed only in BAR mode.

2 Setting menu

-**MODE**

BLACK STRETCH	:OFF
D5600K	:OFF
CABLE COMPE	: Om
SUP GAIN	:OFF
CAM ID	:BAR
CAM ID POSI	:0
MATRIX TABLE	:OFF
COLOR CORRECTION	:OFF
STATUS	:ON

-**SHUTTER**	
SHUTTER MODE SHUTTER SPEED	:OFF :1/100
SYNCHRO SCAN	:75.1



1 Camera mode setting menu (continued from previous page)

CAM ID POSI: It sets the display position of camera ID. 0: top left, 1: top right, 2: down left,

3: down right.

MATRIX TABLE: It sets A, B or OFF of Matrix table.

COLOR CORRECTION: Setting of matrix ON/OFF.

STATUS: It sets displaying/not displaying the status when AWB/ABB is executed.

2 Electronic shutter setting menu

SHUTTER MODE: It selects the shutter operation. ON/SYNCHRO/OFF can be selected.

 $ON \rightarrow Setting of normal discrete shutter speed.$

 $\label{eq:SYNCHRO} \texttt{SYNCHRO} \rightarrow \texttt{Setting of synchro scan} \\ \texttt{mode}.$

SHUTTER SPEED: Setting of normal shutter speed.

SYNCHRO SCAN: Setting of synchro scan mode.

Shutter speeds of 60 Hz to 120 Hz can be continuously changed.

3 Horizontal phase adjustment menu for external reference signal

H.PHASE-COARSE: It is able to set the horizontal phase in 15μ step.

H.PHASE-FINE: Setting of 1-step fine adjustment in the above phase adjustment.

3 Camera ID setting menu

CAM ID	
ID:AKHC900	

4 File managing and renewing menu

FILE MENU -FILE SAVE FILE? SAVE	:USER1 :USER1 :	 File operation menu : blinking display. The file selected by FILE is loaded. It can be selected from [PRESET/USER1 / USER2 /CURRENT]. When desired to return to the previous data after loading other file, select "CURRENT".
FILE MENU FILE SAVE FILE? SAVE	:USER1 :USER1 :	

4 File managing and renewing menu

*FILE MENU	
FILE -SAVE FILE? SAVE	:USER1 :USER1 :


FILE MENU	
FILE SAVE FILE? SAVE IN USER1.OK? -YES NO	:USER1 :USER1


:USER1 :USER1

File operation menu (continued from previous page)

- ② When saving the current data, two files (USER1 /USER2) can be saved. Select the file by "SAVE FILE?" Select "USER1" and move the cursor to SAVE and press the MENU key, then the item menu is displayed.
- ③ SAVE IN USER1. OK? "YES" and "NO" are displayed. Move the cursor from "NO" to "YES" and check that "YES" blinks.
- ④ When the menu key is pressed, "SAVE COMPLETE" appears, then "SAVE" of the file is completed.

(): mm





 \odot

۲

ি

۲

| Specifications

Supply voltage:DC 12V (supplied from D-SUB 15 pins)Power consumption:22 W

indicates safety information.

Image pickup device:	2/3" 2.2 million-pixel FIT CCD×3
System:	GBR image pickup system
Resolving optical system:	F1.4 prism
Optical filter:	CC: clear, 4300K, 6300K, cross
	ND: 100%, 25%, 6.3%, 3.2%
Lens mount:	Bayonet type
Output spec.:	SMPTE 292M
Sensitivity:	F10, 2000lx, 3200K, white reflection rate 89.9%
S/N:	54 dB (Y signal \rightarrow 30 MHz)
Horizontal frequency:	33.716 kHz (1125 lines/frame)
Vertical frequency:	59.94 Hz (interlace)
Ambient temp. for operation	: 0°C to +40°C
Ambient temp. for storage:	-20°C to +60°C
Weight:	Approx. 4.07 lbs (1.85 kg)
Dimensions:	4-3/8″ (W)×5-13/16″ (H) ×7-1/8″ (D)
	110×147×180 mm

Input/output signal

Video output:
SYNC input:
Camera connector:
Control system:
HD-SDI:
Lens connector 1:
Lens connector 2:

Y, PB, PR, each 75 ohm output (signal band → 30 MHz) SYNC input (GL input 3 value SYNC) D-SUB 15-pin connector seat (JAE: DAU-15PF-FO) Synchronous (RS422, 38.4Kbps) BNC 2 system Iris control (HIROSE: HR10A-10R 12SC) Zoom, focus control (HIROSE: HR10A-10R12PC)

Accessories

· Lens cap (1)

Instruction manual (1)

Weight and dimensions shown are approximate. Specifications are subject to change without notice.

Panasonic

PANASONIC BROADCAST & TELEVISION SYSTEMS COMPANY UNIT COMPANY OF MATSUSHITA ELECTRIC CORPORATION OF AMERICA

 Executive Office:

 One Panasonic Way 4E-7, Secaucus, NJ 07094 (201) 348-7000

 EASTERN ZONE:

 One Panasonic Way 4E-7, Secaucus, NJ 07094 (201) 348-7621

 Southeast Region:

 1225 Northbrook Parkway, Ste 1-160, Suwanee, GA 30024 (770) 338-6835

 Central Region:

 1707 N Randall Road E1-C-1, Elgin, IL 60123 (847) 468-5200

 WESTERN ZONE:

 3330 Cahuenga Blvd W., Los Angeles, CA 90068 (323) 436-3500

Government Marketing Department:52 West Gude Drive, Rockville, MD 20850 (301) 738-3840

Broadcast PARTS INFORMATION & ORDERING:

9:00 a.m. - 5:00 p.m. (EST) (800) 334-4881/24 Hr. Fax (800) 334-4880 Emergency after hour parts orders (800) 334-4881

TECHNICAL SUPPORT: Emergency 24 Hour Service (800) 222-0741

Panasonic Canada Inc. 5770 Ambler Drive, Mississauga, Ontario L4W 2T3 (905) 624-5010

Panasonic de Mexico S.A. de C.V. Av angel Urraza Num. 1209 Col. de Valle 03100 Mexico, D.F. (52) 1 951 2127

Panasonic Sales Company Division of Matsushita Electric of Puerto Rico Inc. San Gabriel Industrial Park, 65th Infantry Ave., Km. 9.5, Carolina, Puerto Rico 00630 (787) 750-4300



Printed in Japan VQT0H34

F1003I0 D